


Power Saver User Manual

PURPLE Power Saver

GREEN Power Saver

STEP 1:

**Disconnect power source
to furniture**



STEP 2:

Identify the 5 pin connection to motor
(wire controls buttons to open and close recliner)

Location will vary by manufacturer:

All will connect to motor either directly (as shown)
or with a splitter wire from motor



STEP 3:

Disconnect 5 pin from Motor

Connect PS 5 pin connector to motor
Indicated with letter C

5 pin connector



STEP 4:

Connect 5 pin removed from motor
to 5 pin receiver

Indicated with letter B on reverse

5 pin receiver



STEP 5:

Connect power source to furniture

The LED Power indicator
should illuminate green

